



8/16 Port LCD KVM Switch

JKP115-801e/117-801e

JKP115-1601e/117-1601e

LCD Control Console

JKP115e/117e

User Manual

TABLE OF CONTENTS

JKP115-801e/117-801e & JKP115-1601e/117-1601e LCD KVM SWITCH

MANUAL CONVENTIONS	P1
TECHNICAL SUPPORT	P1
INTRODUCTION	P1
APPLICATIONS.....	P2
OVERVIEW.....	P2
FEATURES	P3
PACKAGE CONTENTS.....	P4
EQUIPMENT REQUIREMENTS.....	P4
SPECIFICATIONS.....	P5
DISPLAY DIAGRAMS.....	P6
INSTALLATION.....	P8
HARDWARE INSTALLATION.....	P9
LCD DISPLAY CONTROLS AND FUNCTIONS.....	P10
SINGLE SWITCH INSTALLATION.....	P13
MULTIPLE STAGE (CASCADING) INSTALLATION.....	P14
CONNECTING EXTERNAL MOUSE.....	P14
OPERATION	P17
HOT KEY OPERATION.....	P17
PORT IDENTIFICATION.....	P17
PORT SELECTION.....	P18
QUICK VIEW SCAN MODE.....	P19
PASSWORD SECURITY – LOCKING SERVER ACCESS.....	P19
BEEPER CONFIRMATION.....	P19
HOT KEY SUMMARY.....	P20
OSD OPERATION	P21
FIRMWARE UPGRADES	P26
JKP115e/117e LCD CONTROL CONSOLE	
OVERVIEW / FEATURES.....	P28
PACKAGE CONTENTS.....	P28
SPECIFICATIONS.....	P29
DISPLAY DIAGRAMS.....	P30
HARDWARE INSTALLATION.....	P31
LCD DISPLAY CONTROLS AND FUNCTIONS.....	P33
FCC, AND CE STATEMENTS	P36

ABOUT THIS MANUAL

Document Conventions

This manual uses different formats to quickly identify information;

[] “ ” Indicates keyboard selection. E.g., [Ctrl], “8” indicates you should press the Control key followed by the numeral 8. Sequenced keys appear with a comma between them: [Ctrl], [Ctrl]

- Bulleted information

1. Numbered lists designate sequenced instructions indicating important information.

Italics Italics Represents text given in reference or as example.



Important Information

Please have the following information ready beforehand:

- Your current computer installation (operating system, configuration details, software etc.)
- Error messages, reports or other information that may assist our staff.

INTRODUCTION

Thank you for purchasing VeloxView LCD Console KVM server management solution. Designed for IT professionals the 8 (JKP115-801e/117-801e) and 16 (JKP115-1601e/117-1601e) port JKP1 series leverages the power of existing server networks with minimal intrusion. Highly efficient it allows centralized access and control of up to 128/256 computers (via Cascading) from an integrated 1U console drawer; with built-in 15” / 17” LCD display, 8 /16 port KVM switch, keyboard and touchpad.

JKP1-KVM series is designed to deliver considerable return on investment; saving time money and valuable server room real estate, it can be rack mounted at any user-height. With a host of advanced features designed to protect your investment, the series includes; intelligent OSD (On Screen Display) menus, Hot Key switching, Auto sensing of cascade computers, Quick View scanning and Firmware upgrades.

Whether it's in educational, government, or corporate sectors, the JKP1 series provides network managers and IT managers a stable management tool for consolidated server access and control.

APPLICATIONS

The JKP115-801eJKP1/117-801e/115-1601eJKP1/117-1601e switch offers IT managers and MIS staff consolidated control of hundreds of computers via a single integrated console. Applications include:

- ISPs / IDCs
- Data centers & server firms
- Test labs

OVERVIEW

OSD (On Screen Display)

An intelligent menu system designed to easily access and control multiple servers.

Hot Keys

Hot keys allow you to use designated key commands to switch computers. Control multiple computers using a simple hot key sequence from your keyboard.

Manual Port Selectors

Push button selectors allow for convenient manual PC selection.

LCD Bank Display

The LCD Bank Display shows bank identification when cascading.

Quick View Scan

The Quick View Scan function allows you to automatically scan and monitor all computers - one by one, that are connected to your JKP1 KVM switch.

Video Resolution

The 15" / 17 " LCD monitor supports 1024 x 768 / 1280 x 1024 @75Hz.

Port LED Display

Port LEDs allow for easy status monitoring of all connected computers. A lit Green LED indicates which computer the KVM console currently has control of. A Red LED indicates which computer is connected but not in use.

Sliding (1U) console Drawer

The entire LCD KVM console simply slides away into a compact 1U rack space when not in use.

FEATURES

- Control 8 and up to 16 computers directly from a single PS/2 console
- Multi Bank installation (Cascaded) - control up to 128 / 256 computers respectively
- Allows users to control up to 8 (JKP115-801e/117-801e) and up to 16 (JKP115-1601e / JKP117-1601e) computers directly from an integrated 1U console drawer
- Control up to 128 / 256 computers respectively via a Cascade installation
- Convenient computer selection via intelligent On Screen Display (OSD) Menus, Hot Keys, or Manual PC Selectors
- Auto-Sensing of Bank Position on Cascade installations
- 7 segment LED display for BANK identification when Cascading
- Quick View Scan for monitoring connected computers
- Console's mouse port or touch pad can be easily used to control connected computers
- Password Security – lock access to connected servers
- No software required for installation
- Hot Pluggable - add / remove computers without powering down the Switch
- Keyboard and mouse emulation – intelligently manages booting via independent channel microprocessors
- Optional 15" / 17 " RGB LCD monitor supporting 1024 x 768 / 1280 x 1024 @75Hz
- 1U rack mountable at any user height in a (19") system rack – console drawer simply slides away when not in use

New Rackmount Advantages

- One person installation saves valuable human resources and time.
- Quick release rack-mount draw thumbscrews
- Adjustable rack slides for convenient positioning in 22"-36" server racks.

PACKAGE CONTENTS

Item	Qty	Remark
JKP115-801e / 117-801e/ JKP115-1601e / 117-1601e	1	19"Rackmount LCD KVM drawer
Power adapter	1	
Bracket	2	
User Manual	1	
Flash Cable	1	
Power Cord	1	

Please check to make sure that each item of the above list is included in your JKP1 package. Contact your dealer immediately if any item is missing or damaged in shipment.

EQUIPMENT REQUIREMENTS

Cables

It is highly recommended that you use only our KVM Cable sets. These cables offer the highest quality possible to ensure optimal data transmission. our KVM cables feature micro-cable construction and are molded together for a neat and organized setup.

All-in-one KVM Cable set includes an industry-standard, coaxial VGA cable and nickel-plated connectors for high-resolution applications.

The following cables are recommended for your JKP1 KVM installation:

Single Installation / Multiple Installations (Cascaded):

- K15C6P (L=1.8M)
- K15C9P (L=3.0M)
- K15C0P (L=4.8M)

Power Supply

- An AC 100-240V 50-60Hz is recommended

Operating Systems

- Windows [®] 98/Me/NT/2000/XP/2003 server, FreeBSD, Linux[®], Novell[®] NetWare [®] 4.x/5.x

Computers

- Keyboards - 6 Pin PS/2 mini DIN
- Mice - 6 Pin PS/2 mini DIN
- Monitors - VGA ,SVGA, MultiSync[®]

SPECIFICATIONS

	JKP115-801e	JKP115-1601e	JKP117-801e	JKP117-1601e
Display Area (mm)	704.128(H) x 228.096(V) (15.0" diagonal)		717.824(H) x 270.344(V) (16.0" diagonal)	
Pixel Pitch	0.297(H) x 0.297(V)		0.264(H) x 0.264(V)	
Number of Pixels	1024(H) x 768(V)		1280(H) x 1024(V)	
Contrast Ratio	(400:1)		(500:1)	
Display Color	360, #4		16.2M	
Brightness (CD/m ²)	250(CD/m ²)		700(CD/m ²)	
Input Signal	RGB+Analog			
Keyboard and Key Pad	106 key PS/2 keyboard with touch pad			
Power Supply	AC 100-240V 50-60Hz			
LCD On-Screen Display	Auto. Brightness, Contrast, Horizontal, Vertical, Color, OSD BP, OSD VP, OSD Time, Language, Recall, Exit			
Port Selection	OSD / Exit Key / Push Button			
Computer Port Connector	HDD, D-Sub Female (Keyboard, Mouse, VGA)			
Computer Connections (Direct)	3	16	3	16
Computer Connections (Cascading)	128	256	128	256
Port LEDs	3	16	3	16
Port Switch Button	3	16	3	16
Temperature	0- 40 deg. C. in operating, -20- 60 deg. C. in storage			
Humidity	0- 80% RH, non-condensing			
Housing	Metal			
Size & Weight	448 x 360.52 x 44.25mm, 1.06kg		448 x 390.52 x 44.25mm, 1.11kg	
Flash Upgrade	Firmware Upgradeable			

Note: Specifications are subject to change without notice.


DISPLAY DIAGRAMS

Front View



1. Console Drawer Handle
2. LCD Display (15"/17")
3. LCD Display Control (see the LCD Display Guide for details)
4. Power Switch
5. LCD Bank Display
6. External Mouse Port
7. Touchpad
8. Mouse & Touch Pad Switch
9. Rack Mounting Brackets
10. Manual Port selectors (1-8 / 1-16)

Rear View



1. DC Input
2. Firmware Upgrade Port
3. PC Ports

INSTALLATION

Where to Place the Switch

The enclosure of the JKP1 Switch is designed for standalone or rack-mount configuration. The Switch is natively rack-mountable in a standard 1U (19") server rack. Rack-mount hardware is included with your switch for a sturdy rack installation.

Cautions and Warnings

Avoid placing cables near machines that create electrical noise such as fluorescent lighting, air conditioning equipment, etc.

Important Information



Before you begin, make sure that power to all the computers you will be connecting has been powered off.

To prevent damage to your installation due to ground potential difference, make sure that all computers on the installation are properly grounded. Failure to follow these instructions can result in damage to computers and / or the Switch.

Installing the Switch into a Server Rack

Unlike other traditional rack mounted LCD KVM units the JKP1 series requires only one person for installation. The JKP1 series includes 2 adjustable sliding rack mount brackets for installation in 19-inch rack systems. The sliding brackets feature adjustable positions for rack depths of 22-36 inches.

Important Information




Installing and or removing the Switch (module and chassis) improperly could void your warranty. If you are uncertain what to do please contact our technical support.


Please follow these simple steps to install the JKP1 into a server rack:

1. Adjust the sliding rack mount brackets to match the depth of your server cabinet. Fix both brackets at a desired height to the server cabinet rails.

(Note: The slider brackets are extendable to a rack depth of 22" to 36".)




2. Gently slide the JKP1 chassis into the fixed brackets of the rack rail assembly.




3. Fasten the front-end bracket screws. Your JKP1 Switch is now ready for use; locate the handle, slide out the console and flip the LCD cover.

(Note: The front-end bracket screws must be fastened to properly secure the JKP1 chassis to the server rack.)



LCD FLAT PANEL DISPLAY

Panel Controls and OSD Functions



- Press "MENU" Button, display will show following picture.
- Continue to press "◀" and "▶" button to select function. Then, press "SEL" to enter these functions and adjust them to your personal

Auto	Brightness	Contrast	Horizontal
Vertical	Color	OSDHP	OSDVP
OSD Time	Language	Recall	Exit

Controls	
Power On/Off switch	Soft power on/off button. Adjacent LED is lit when on.
Auto	Auto-synchronize and scale down display to any valid factory preset timings.
◀	Press to scroll the function you want to adjust.
▶	Press to scroll the function you want to adjust.
Menu	To access the main menu. This button also acts as the "Enter" button.

Auto

Auto tracking, positioning, phase and size

1. Press the "Menu" button.
2. Use the "◀" and "▶" button to scroll.

Auto	Brightness	Contrast	Horizontal
Vertical	Color	OSDHP	OSDVP
OSD Time	Language	Recall	Exit

3. Press the "SEL" button to enter.
4. Use the "◀" and "▶" button to adjust the brightness of the display.
5. Press the "SEL" button to go back to main menu.

Brightness

Adjust LCD brightness level 0-255 of the image.

1. Press the "Menu" button.
2. Use the "◀" and "▶" button to scroll.

Auto	Brightness	Contrast	Horizontal
Vertical	Color	OSDHP	OSDVP
OSD Time	Language	Recall	Exit

3. Press the "SEL" button to enter.
4. Use the "◀" and "▶" button to adjust the brightness of the display.
5. Press the "SEL" button to go back to main menu.

Contrast

Adjust white color level 0-255 of the image.

1. Press the "Menu" button.
2. Use the "◀" and "▶" button to scroll.

Auto	Brightness	Contrast	Horizontal
Vertical	Color	OSDHP	OSDVP
OSD Time	Language	Recall	Exit

3. Press the "SEL" button to enter.
4. Use the "◀" and "▶" button to adjust the brightness of the display.
5. Press the "SEL" button to go back to main menu.

Horizontal

Adjust LCD display horizontal level 0-255

Vertical

Adjust LCD display vertical level 0-255

Recall

Adjust LCD setting back to previous setting

Color

ICON	Description
9300	To set CIE coordinate at 9300 color
6500	To set CIE coordinate at 6500 color
Gain	R/G/B: 0-255
Offset	R/G/B: 0-255

OSDHP

Adjust OSD horizontal level 0-255

OSDVP

Adjust OSD vertical level 0-255

OSD TIME

Adjust OSD time 5-60 seconds

Language

Chinese, English

Recall

Adjust LCD setting back to previous setting

Power Indicator


- GREEN ON
- ORANGE STANDBY
- ORANGE SUSPEND
- None OFF

SINGLE SWITCH INSTALLATION

This section provides complete instructions for the hardware setup of a single JKP1-KVM switch in which there are no other KVM switches cascaded.

Connecting the Computers


1. Power off all computers.
2. Using all-in-one KVM Cable set (Part No. K15C6P) take the male (HDDB-15pin) connector and plug it into the PC1 port indicated on the rear of the KVM Switch. Connect the other male VGA (HDDB-15) cable end to the VGA port of the computer you're installing.
3. Connect the PS/2 keyboard and mouse connectors of the KVM cable set to the corresponding keyboard and mouse ports on the computer.



4. Repeat step 1 and 2 for each additional computer you wish to connect.

Connecting the Power Supply

1. Connect the power cord to the power jack on the rear of the Switch. Then plug the power cord into an available power outlet.
2. Power on the Switch's LCD display.
3. Power on your computers.



Connecting your External Mouse

To select a mouse option, do the following:

Switch to External Mouse port use

1. Select the External mouse from the switch located on the front panel of the JKP1 KVM switch.
2. Connect your external mouse to the mouse port located on the front panel of the JKP1 KVM switch.

Switch back to Touchpad Mouse use

Select the Touchpad mouse from the switch located on the front panel of the JKP1 KVM switch.

MULTIPLE STAGE INSTALLATION


Cascading

This section provides complete instructions for the hardware setup of installing cascaded computers. To control even more computers, up to 8 (JKP115-801e/117-801e) and 16 (JKP115-1601e/117-1601e) additional switches can be cascade from the CPU ports of the First Stage (Master) switch. The cascaded Switches that connect back to the First Stage switch are referred to as Second Stage switches (or BANKS) and assigned a location. For example; the Console keyboard, monitor and mouse connects to BANK 00 or the "Master" switch. As many as 128 / 256 computers can be controlled by a system administrator in a complete multi-bank installation.

To set up a Multiple Stage Installation, do the following;


1. Power off all computers.
2. Using the all-in-one KVM Cable set (Part No. K15C6P). Take the male (HDDB-15pin) connector and plug it into the PC1 port indicated on the rear of the KVM Switch. Connect the other male VGA (HDDB-15) cable end to the console VGA port of the second stage switch.

3. Connect the PS/2 keyboard and mouse connectors of the KVM cable set to the second stage switch's console keyboard and mouse ports.



Note : The above working diagram represents an JKP1610LS (16 port) KVM switch cascaded with the JKP115-801e/17JKP1 KVM switch.


4. Using the all-in-one KVM Cable set (Part No. K15C6P) take the male (HDDB-15pin) connector and plug it into the PC1 port indicated on the rear of the second stage switch. Connect the other male VGA (HDDB-15) cable end to the VGA port of the computer you're installing.
5. Connect the PS/2 keyboard and mouse connectors of the KVM cable set to the corresponding keyboard and mouse ports on the computer.



6. Repeat steps 2 and 3 for any other compatible KVM switches you wish to add to the installation. Then repeat steps 4 and 5 for each additional computer you wish to connect.

Connecting the Power Supply

1. Connect the power cord to the power jack on the rear of the JKP1 KVM switch. Then plug the power cord into an available power outlet.
2. For all KVM switches attached, connect in turn, the “DC 9V, 600mA” power adapter to the power jack on the rear of each switch.



3. Power on all computers.
4. Perform a Manual Reset of the “Master” KVM switch by pressing the Port 1 and Port 2 manual push button selectors simultaneously for 2 seconds. All port LEDs of the “Master” switch will flash green for reset confirmation.

Confirmation Procedure

Once all computers are powered on, the switch emulates both mouse and keyboard signals on each port allowing your computer to boot normally without errors.

To make sure your Cascade installation was successful, do the following:

1. Press **[SCROLL LOCK]** twice and enter your 4 digit port ID code.
For example: if Cascading is successful, press [SCROLL LOCK], [SCROLL LOCK], “0101”, then the monitor will show PC1’s screen.
2. Check to see that the keyboard, monitor, and mouse are working normally. Proceed to do this with all occupied ports to verify that all computers are connected and responding correctly. If you encounter an error, check your cable connections for that computer and reboot.

OPERATION

Controlling your computers with the JKP1 series couldn't be easier. The JKP1 series allows you to access the computers using three simple methods:

- Hot Keys
- Manual Selectors
- OSD (On Screen Display) Menu

PC Manual Selectors

You can select any computer or access any Bank by using the PC selectors located at the top left of the console draw.

Manual Selectors

You can directly select any single computer or access any connected Bank by using direct-access PC selectors located at the top left of the KVM console. Each port switch has a corresponding LED for easy status monitoring. A Green LED indicates current port selection (Selected). A Red LED light indicates a port is not selected but the connected computer is powered and ready (Online). The JKP1 series is also equipped with seven-segment LCD display for BANK identification when cascading.

HOT KEYS

Port Identification

Each computer in a JKP1 installation has a specific port ID. You can directly switch the KVM focus to any computer by entering the switch port number and the BANK number (for cascaded installations). Each is assigned a two-digit numeric ID.

Single Switch Installation

- The Port number (X) is a two-digit number that identifies the port on the JKP1 KVM switch that the computer is connected to.

For example, a computer connected to Port 8 has the numeric ID of 08.

Multiple Switch Installation (Cascading)


- The Port number (X) is a two-digit number that identifies the port on the KVM switch that the computer is connected to.
- The BANK number (Y) is a two-digit number that identifies the Switch's position in the cascade installation. (Note: the BANK number always precedes the Port number.)

For example, a computer connected to Port 8 of BANK 6 has the numeric ID of: **0608**

Selecting the Active Port


Directly switch the KVM focus to any computer by entering the Port number and / or the BANK number.

Single Stage Installation:



For example, To access a PC with the port ID 08:
Press [SCROLL LOCK], [SCROLL LOCK], "08".
To access a PC with the port ID 05:
Press [SCROLL LOCK], [SCROLL LOCK], "05".

Multiple Switch Installation / Cascade:



Note: The above working diagram represents an JKP1610LS (16 ports)KVM Switch cascade with the JKP115-801e/117-801e KVM Switch.

For example, To access a PC with the port ID 0008:
Press [SCROLL LOCK], [SCROLL LOCK], "0008".
To access a PC with the port ID 0702:
Press [SCROLL LOCK], [SCROLL LOCK], "0702".

Reset PC Name

This function resets PC Name settings to default values.

Quick View Scan Mode

The Quick View Scan feature allows you to monitor the activity of the connected computers at regular intervals so that you can monitor the computer activity without having to take the trouble of switching yourself. This time interval can be changed as desired.

Note: 1. The interval between these two keys should be no more than 0.5 seconds. Once the scanning begins, it continues until you press any key to exit Quick View Scan Mode.

2. A Port LED will flash indicating that the connected computer is under Auto Scan mode.

Setting the Quick View Scan Time

The scan time or the time the Switch spends on each port can be changed using either Hot Keys or OSD.

Password Security – Locking Server Access

Administrators can set a unique password to restrict access to computers connected to the JKP1 switch.

Changing your Password

To set a new password, do the following:

1. Invoke the Hot Key mode by pressing the **[SCROLL LOCK]** key twice within two seconds.
2. Key in **[R]**
3. Enter old password (up to 15 characters).

ENTER PIN:

4. Enter the new password (up to 15 characters).

NEW PIN:

5. Re-enter the new password for confirmation.


AGAIN PIN:

Hotkey Beeper Confirmation

The beeper function can be turned on and off as desired using the following Hotkey sequence:

HOT KEY COMMANDS SUMMARY

- On-Screen Port Identification tag
- Previous active channel
- Next active channel
- Switch to Port X (X = 01-16)
- Switch to Port X on Bank Y (Y = 00-16) (cascading)
- Previous active bank
- Next active bank
- Switch to Master switch
- Enable OSD Mode
- Set OSD display time; 7 sec
- Set OSD display time; 15 sec
- Set OSD display time; 30 sec
- Set OSD display time; 60 sec
- Reset OSD menu
- Reset PC Name
- Quick View Scan mode
- Stop Quick View Scan mode
- Turn On / Off Beep confirmation (1 beep = ON, 2 beeps = OFF)
- Set Quick View Scan time; 7 sec
- Set Quick View Scan time; 15 sec
- Set Quick View Scan time; 30 sec
- Set Quick View Scan time; 60 sec
- Set Alternative "Shift" Hot Key
- Set Default "Scroll Lock" Hot Key
- Set Password
- Change Password



Note : 1.The [SCROLL LOCK] key must be pressed within 2 seconds.

2. The "Shift" key can be another Hot Key choice.

3. You will find that after the KVM unit switches to another computer, there is a mouse-keyboard delay of

1-2 seconds. This is normal and ensures re-synchronization of the console and connected computers.

OSD OPERATION

The On Screen Display (OSD) is an intelligent menu system designed to help administrators set up and easily access and control a multiple server installation. The menu driven interface consists of a main Overview menu and an Administrative sub-menu from which users can perform multiple tasks from naming servers to configuring operations.

The superimposed OSD overlay screen is generated by the Switch and does not affect your computers or software in any way.

OSD Overview Menu

The main On Screen Display (OSD) menu can be accessed by doing the following:

1. Press the [SCROLL LOCK] key twice followed by the **"Space bar"**. The OSD overlay screen appears.

OVERVIEW		
NAME	PWR	Port
1 [COMPUTER 1]	☀ E	0.1
2 [COMPUTER 2]		0.2
3 [COMPUTER 3]		0.3
4 [COMPUTER 4]		0.4
5 [COMPUTER 5]	☀	0.5
6 [COMPUTER 6]		0.6
7 [COMPUTER 7]		0.7
8 [COMPUTER 8]		0.8

HOME-MASTER	ENTER-SELECT
↑/↓-UP/DOWN	INS-RENAME
SPACE SPACE-ADMIN	ESC-EXIT



Note: When Hot plugging computer ports you must manually 'refresh' (exit and re-enter) the OSD menu to display the new status information of the corresponding port.

The OSD Overview Menu displays a list of connected computers, controls and function keys as well as symbols that refer to the status of each computer.

Navigation

Use the following to navigate through the OSD menu:

- To escape from the OSD menu or sub-menu, press the [Esc] key.
- To move up and down through the screen list use the Up / Down arrows.
- Move the highlight bar to the desired location and press [Enter] to activate a port.

OSD Heading	Description
NAME	Port or server name that is designated by the user. (See OSD Functions in the next section under Port Naming).
PWR	The  symbol indicates that the computer connected to that port is powered on. If a computer is connected and powered on, but the OSD menu does not display a  symbol, reset the Switch in order to re-detect the server. To reset the Switch press the Port 1 and Port 2 manual push button selectors simultaneously for 2 seconds An E Symbol displays when cascading computers.
PORT	Lists the port identification numbers for all connected servers. The 2 digits (read left-to-right) consist of the BANK and PORT number respectively. To gain access to a computer move the highlight bar over a server in the name list and hit [Enter]. To gain BANK level access when cascading computers, move the highlight bar over a server in the name list and press [SCROLL LOCK] twice to display the BANK OSD. For example; a cascaded KVM switch connected to the Master switch Port 2 will show the preceding BANK numeral as '2'.

OSD Main Menu Functions

This section provides details on the use of the following OSD functions; HOME-MASTER, UP/DOWN, SPACE-ADMIN, ENTER, INS and ESC.

From the main OSD mode, the following OSD functions can be accessed:

HOME-MASTER

To return the KVM focus to the Master switch's first active port press **[Home]** from the keyboard.

UP / DOWN

To select any computer at the same KVM stage, move the highlight bar using the **[Up]** / **[Down]** arrow keys and press **[Enter]**. (e.g. Bank 01 Ports 01 to 16 / Bank 00 Ports 01 to 16)

Accessing computers using the OSD:

To access computers of the Master Switch

1. Invoke the Hot key mode by pressing the [SCROLL LOCK] key twice within two seconds.
2. Key in [SPACE]
3. Move the highlight bar between 1 and 8.
4. Press [ENTER] to gain access to the computer shown with a ☀ symbol.

(Note: the OSD display will be dismissed after [ENTER] is pressed.)

OVERVIEW		
NAME	PWR	Port
1 [COMPUTER 1]	☀	0.1
2 [COMPUTER 2]		0.2
3 [COMPUTER 3]		0.3
4 [COMPUTER 4]		0.4
5 [COMPUTER 5]	☀	0.5
6 [COMPUTER 6]		0.6
7 [COMPUTER 7]		0.7
8 [COMPUTER 8]		0.8

HOME-MASTER	ENTER-SELECT
↑/↓-UP/DOWN	INS-RENAME
SPACE SPACE-ADMIN	ESC-EXIT

To access computers of the Slave Switch

1. Invoke the Hot key mode by pressing the [SCROLL LOCK] key twice within two seconds.
2. Key in [SPACE]
3. In the OSD of the Master Switch, move the highlight bar to the cascaded port shown with an “E” symbol.

OVERVIEW		
NAME	PWR	Port
1 [COMPUTER 1]	☀ E	0.1
2 [COMPUTER 2]		0.2
3 [COMPUTER 3]	☀	0.3
4 [COMPUTER 4]		0.4
5 [COMPUTER 5]		0.5
6 [COMPUTER 6]		0.6
7 [COMPUTER 7]		0.7
8 [COMPUTER 8]		0.8

HOME-MASTER	ENTER-SELECT
↑/↓-UP/DOWN	INS-RENAME
SPACE SPACE-ADMIN	ESC-EXIT

According to the previous OSD, port 1 of the Master Switch is cascaded. In order to access the Slave Switch, move the highlight bar to port 1 and press [ENTER] to access the slave switch.

4. Press [SCROLL LOCK] key twice within two seconds.
5. Key in [SPACE].
6. Move the highlight bar from 1 to 8 to select the desired computer and press ENTER

OVERVIEW		
NAME	PWR	Port
1 [COMPUTER 1]		1.1
2 [COMPUTER 2]	☀	1.2
3 [COMPUTER 3]		1.3
4 [COMPUTER 4]		1.4
5 [COMPUTER 5]		1.5
6 [COMPUTER 6]	☀	1.6
7 [COMPUTER 7]		1.7
8 [COMPUTER 8]		1.8

HOME-MASTER	ENTER-SELECT
↑/↓-UP/DOWN	INS-RENAME
SPACE SPACE-ADMIN	ESC-EXIT

Note: the JKP1 series is designed for 2 levels of cascading only.

Returning to the Master Switch Using OSD

1. Invoke the Hot key mode by pressing the [SCROLL LOCK] key twice within two seconds.
2. Key in [SPACE]
3. Key in [Home]

Note: After switching back to the Master switch, port 1 of the Master switch is always the first to be shown.

SPACE SPACE - ADMIN

To access the Administration sub-menu press [SPACE], [SPACE] from the main OSD menu. (see next section for details).

ENTER

To confirm a selection and save the content input press **[ENTER]**.

OVERVIEW		
NAME	PWR	Port
1 [COMPUTER 1]	E	0.1
2 [COMPUTER 2]		0.2
3 [COMPUTER 3]		0.3

[ESC]

To exit the current OSD menu press **[ESC]**.

OSD Administration Sub-Menu

This section provides details on configuring default Hot keys to setting up user password access.

To access the Administration sub-menu complete the following:

1. Press **[SPACE]**, **[SPACE]** from the main OSD menu (see above). The OSD overlay screen appears.

ADMINISTRATION	
CHANGE HOT KEYS	
CHANGE SCAN TIME	
CHANGE DISPLAY TIME	
FIRMWARE INFORMATION	
CHANGE PASSWORD	
RESET	
↑ -MOVE UP	ENTER-SELECT
↓ -MOVE DOWN	ESC-EXIT

OSD Function	Description
CHANGE HOT KEYS	Changes the default HOT Key option (Scroll Lock <-> Shift)
CHANGE SCAN TIME	Quick View Scan allows users of large installations hands-free automatic scanning and viewing of all connected ports for a selected time interval. You may choose 7, 15, 30, or 60 seconds.
CHANGE DISPLAY TIME	Changes the amount of time the OSD menu is displayed on-screen and also specifies the amount after making a port selection. You may choose 7, 15, 30, or 60 seconds.
FIRMWARE INFORMATION	Indicates version and make of your JKP1 KVM switch.
CHANGGE PASSWORD	Modify and/or delete user passwords.
RESET	Resets OSD function setting to default values (server names designated by the administrator are NOT affected). Perform an OSD Reset when Daisy Chaining or when keyboard / mouse inactivity is experienced. NOTE: Pressing [SCROLL LOCK], [SCROLL LOCK], [Delete] will reset the OSD to its factory default settings.

FIRMWARE UPDATES

Firmware upgrades enable your KVM switch to maintain consistent compatibility with the latest devices and computers. Firmware upgrades are free for the life of your JKP1 KVM switch. Refer to the Windows flash upgrade instructions below for the latest upgrade software, information and support.

To update the firmware, you will need the following items:

1. A separate computer running Windows 95/98/ME/2000 or XP. This computer must not be connected to the CPU ports on your KVM switch.

2. An available serial port on the computer.
3. A custom serial cable (8 pin to RS232 9 pin) included in package .
4. Firmware update files available at customer support web site.

Set Up

To setup for the flash upgrade, do the following:

1. Open the firmware upgrade program by double clicking on the latest firmware file from customer support web site.
2. Use a computer that is not connected to your KVM computer ports.



3. Connect the power cord to the power jack of the KVM switch. Then plug the power cord into an available power outlet.
4. Using a serial cable (8 pin to RS232 9 pin) connect an available COM port on your computer. Take the other cable end and connect it to the FLASH port on the rear of the KVM switch.



LCD CONTROL CONSOLE

JKP115e/117e

OVERVIEW

The JKP115e/117e is a rackmounted control console designed for 19" rack systems. The JKP115e/117e is designed for the control and access of server farms or automation applications.

The JKP115e/117e integrates a 15/17 inch color TFT LCD module, which supports up to XGA (1024 x 768) and 16.7M, 8 bit color. The new innovative design with heavy-duty steel housing and aluminum front bezel meets tough environmental standards.

Whether it's in educational, government, or corporate sectors, the JKP115e/117e provides network administrators and IT managers a stable management tool for server access and control.

FEATURES

- . Stable management tool
- . 1U, 19" design for universal setting
- . 15" / 17" color TFT-LCD module
- . 3 Step rack mount installation
- . Easy maintenance

PACKAGE CONTENTS

The complete JKP115eRM/117e package consists of:

Item	Qty	Remark
JKP115eRM/117e	1	19" Rackmount LCD KVM console drawer
Power Cord	1	
Power Adapter	1	
Bracket	2	
User Manual	1	
KVM Cable	1	

Check to make sure that the unit was not damaged during shipment. If you encounter a problem, contact your dealer.

Please read this manual thoroughly. Follow the installation guide and operation procedures carefully to prevent any damage to the JKP115eRM/117e, and/or any of the devices that connect to it.

SPECIFICATIONS

	JKP115e	JKP117e
Display Area (mm)	304.128(H) x 228.096(V) (15.0"diagonal)	337.92(H) x 270.34(V) (17.0"diagonal)
Pixel Pitch	0.297(H) x 0.297(V)	0.264(H) x 0.264(V)
Number of Pixels	1024(H) x 768(V)	1280(H) x 1024(V)
Contrast Ratio	(400 :1)	(500:1)
Display Color	262 , 144	16.2M
Brightness(CD/m ²)	250(CD/m)	300(CD/m)
Input Signal	RGB Analog	
Computer Port Connector	Keyboard:PS/2	Mouse:PS/2 VGA: 15-pin D-Sub
Computer/ KVM Connections	1	
Keyboard and Key Pad	106 key PS/2 keyboard with touch pad	
Power Supply	AC100-240V 50-60HZ	
On-Screen Display	Auto, Brightness, Contrast, Horizontal, Vertical, Color, OSDHP, OSDVP OSD Time, Language, Recall, Exit	
Temperature	0-40 deg .C In operating ; -20-60 deg. C in storage	
Humidity	0 – 80% RH,non-condensing	
Size & Weight	448.20 x 560.52 x 44.25 mm, 10.3kg	448.20 x 560.52 x 44.25 mm, 10.7kg

Note: Specifications are subject to change without notice.

DISPLAY DIAGRAMS

Front View



1. Console Drawer Handle
2. LCD Display (15"/17")
3. LCD Display Controls
4. External mouse port
5. Touchpad and keyboard
6. Mouse and touch Pad switch
7. Power LED
8. Power Switch
9. Rack mounting Brackets

Rear View



1. DC input
2. CPU Port

Connect your computer / KVM switch here.

HARDWARE REQUIREMENT

Computer

- 6 Pin PS/2 mini DIN, keyboard port.
- 6 Pin PS/2 mini DIN, mouse port.
- VGA ,SVGA, MultiSyncR.

Above equipment must be built in one computer.

KVM

The KVM console must support the following specification.

- 6 Pin PS/2 mini DIN, keyboard port.
- 6 Pin PS/2 mini DIN, mouse port.
- VGA ,SVGA, MultiSyncR.

Installing the Switch into a Server Rack

Unlike other traditional rack mounted LCD KVM units the RM series requires only one person for installation. The RM series includes 2 adjustable sliding rack mount brackets for installation in 19-inch rack systems. The sliding brackets feature adjustable positions for rack depths of 22-36 inches.

Important Information




Installing and or removing the Switch (module and chassis) improperly could void your warranty. If you are uncertain what to do, please contact Technical support.


Please follow these simple steps to install the RM into a server rack:

1. Adjust the sliding rack mount brackets to match the depth of you're your server cabinet. Fix both brackets at a desired height to the server cabinet rails.


(Note: The slider brackets are extendable to a rack depth of 22" to 36")



2. Gently slide the RM chassis into the fixed brackets of the rack rail assembly.




3. Fasten the front-end screws. Your RM Switch is now ready for use; locate the Smart handle, slide out the console and flip the LCD cover. (Note: The front-end screws must be fastened to properly secure the RM chassis to the server rack.)




Installation of JKP115eRM/117e

1. Plug the VGA/Mouse/Keyboard cable to the JKP115eRM/117e unit. The other end plugs into the computer or KVM's console.
2. Plug the power cord into JKP115eRM/117e's power jack, then plug the power cord into an AC power source.
3. Turn the JKP115eRM/117e on by pushing the Power-on button.



LCD FLAT PANEL DISPLAY

Panel Controls and OSD Functions



- Press "MENU" Button, display will show following picture.
- Continue to press "◀" and "▶" button to select function. Then ,press " SEL" to enter these functions and adjust them to your personal

Auto	Brightness	Contrast	Horizontal
Vertical	Color	OSDHP	OSDVP
OSD Time	Language	Recall	Exit

Controls	
Power On/Off switch	Soft power on/off button. Adjacent LED is lit when on.
Auto	Auto-synchronize and scale down display to any valid factory preset timings.
◀	Press to scroll the function you want to adjust.
▶	Press to scroll the function you want to adjust.
Menu	To access the main menu. This button also acts as the "Enter" button.

Auto

Auto tracking, positioning, phase and size

1. Press the "Menu" button.
2. Use the "◀" and "▶" button to scroll.

Auto	Brightness	Contrast	Horizontal
Vertical	Color	OSDHP	OSDVP
OSD Time	Language	Recall	Exit

3. Press the "SEL" button to enter.
4. Use the "◀" and "▶" button to adjust the brightness of the display.
5. Press the "SEL" button to go back to main menu.

Brightness

Adjust LCD brightness level 0-255 of the image.

1. Press the "Menu" button.
2. Use the "◀" and "▶" button to scroll.

Auto	Brightness	Contrast	Horizontal
Vertical	Color	OSDHP	OSDVP
OSD Time	Language	Recall	Exit

3. Press the "SEL" button to enter.
4. Use the "◀" and "▶" button to adjust the brightness of the display.
5. Press the "SEL" button to go back to main menu.

Contrast

Adjust white color level 0-255 of the image.

1. Press the "Menu" button.
2. Use the "◀" and "▶" button to scroll.

Auto	Brightness	Contrast	Horizontal
Vertical	Color	OSDHP	OSDVP
OSD Time	Language	Recall	Exit

3. Press the "SEL" button to enter.
4. Use the "◀" and "▶" button to adjust the brightness of the display.
5. Press the "SEL" button to go back to main menu.

Horizontal

Adjust LCD display horizontal level 0-255

Vertical

Adjust LCD display vertical level 0-255

Recall

Adjust LCD setting back to previous setting

Color

ICON	Description
9300	To set CIE coordinate at 9300 color
6500	To set CIE coordinate at 6500 color
Gain	R/G/B: 0-255
Offset	R/G/B: 0-255

OSDHP

Adjust OSD horizontal level 0-255

OSDVP

Adjust OSD vertical level 0-255

OSD TIME

Adjust OSD time 5-60 seconds

Language

Chinese, English

Recall

Adjust LCD setting back to previous setting

Power Indicator

- GREEN ON
- ORANGE STANDBY
- ORANGE SUSPEND
- None OFF

FCC CERTIFICATIONS

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.
- . Shielded interface cables must be used in order to comply with emission limits.
- . You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.
- . This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

VCCI Warning

注意

この装置は、情報処理装置等電波障害自主規制協議会 (VCCI) の基準に基づく第一種情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。