

Resetting new IP KVM password to default

Resetting new IP KVM password to default value

Troubleshooting Procedures:

1. Connect the power supply to IP-KVM switch.
2. Connect the **IP serial cable*** (4-conductors 2.5mm Jack to DB9 serial cable) to IP-KVM switch flash port and PC serial port.
3. Use a terminal software (e.g. hyper term or minicom) to connect to IP-KVM switch.
4. Setting for Hyper term are:
Bit rate: 115,200 bit per second
Data bits: 8
Parity: None
Stop bits: 1
Flow Control: None
5. Power cycle IP-KVM switch and immediately press < ESC >.
6. You will see some device information and a “=>” prompt. Enter the command 'defaults' and press < Enter > (see figure.1)





Figure 1

7. After waiting a few moments you may get some information as below (see figure.2)



```
0
=> defaults
Please wait...
Installing default configuration ...
Writing configuration data to flash ...
Done.
Rebooting...
```

Figure 2

8. At the end of this procedure, You will get the message, "Rebooting.....".

-End-

*** Remarks:**

We carry the IP serial cable, pls check for price & availability if needed.