


How-To connect NE-6 Cable



The **yellow** VGA connector is connected to LCD/Keyboard Drawer



For PS/2 connection

The **blue** VGA connector is connected to PC/servers system.

The **black+purple** one is for keyboard and **green** one is for mouse signal.



For USB connection

The **blue** VGA connector is connected to PC/servers system.

The **black** one is for both keyboard & mouse signal.

**** No need to plug in the green one.**