

HOW TO KNOW VERSION OF THE FIRMAWARE OF THE NETVIEW KVM

See attached picture as a sample.
In the bottom right corner, you will see the KVM firmware version.

