

Instruction to change NX and SNK Touchpad/Trackball

Step 1: Remove keyboard cover (11 screws as show in red circle)



Step 2: Release 4 touchpad screws holder a little bid. Click the mouse button see if it works fine.

